

# **TOGE TSM BC**

Shear-Connector Fast and economical solution for the rehabilitation of structures

#### Approval

Approved by building authorities as shearconnector.

#### Accessories

Hole corrugation disc optionally serves to support or tie the rebars.

**Installation** Fast and safe installation.

Force Transmission

Transmission of forces in existing concrete by undercutting technique.

Transmission of forces in the new concrete via shear studs.

### Approval

#### Approval

General type approval / General technical approval Z-21.1-1799.

General type approval / General technical approval Z-21.1-1880.


#### **Base Material**

Application in cracked and non-cracked concrete of strength classes from C20/25 to C50/60.



# **Technical Characteristics**





### **Processing in existing concrete**

Ankergröße			TSM BC 12
			13141 BC 12
Nominal diameter of drill bit	d <sub>o</sub>	[mm]	12
Depth of drill hole	h, ≥	[mm]	110
Embedment depth of anchor	h <sub>nom</sub>	[mm]	100
Effective anchorage depth	h <sub>ef</sub> ≥	[mm]	80
Minimum edge distance	C <sub>min</sub> ≥	[mm]	80
Minimum spacing	S <sub>min</sub> ≥	[mm]	80
Minimum base material thickness	h <sub>min</sub> ≥	[mm]	150
Characteristic edge distance	C <sub>cr, N</sub>	[mm]	120
Characteristic spacing	S <sub>cr, N</sub>	[mm]	240
Design value of tension load in cracked concrete C 20/25 $^{1 m (3)}$	N <sub>Rd</sub>	[kN]	17,2
Design value of tension load in non-cracked concrete C 20/25 $^{1\!$	N <sub>Rd</sub>	[kN]	23,9
Design value of shear load in cracked and non-cracked concrete C 20/25 bis C 50/60 $^{1\!\!13\!\!1}$	V <sub>Rd</sub>	[kN]	28,0
Permissible tension load in cracked concrete C 20/25 <sup>2) 3)</sup>	N <sub>per</sub>	[kN]	12,3
Permissible tension load in non-cracked concrete C 20/25 $^{2(3)}$	N <sub>per</sub>	[kN]	17,1
Permissible shear load in cracked and non-cracked concrete C 20/25 bis C 50/60 $^{\rm 2)3)}$	V <sub>per</sub>	[kN]	20,0

<sup>1)</sup> For the determination of the design value the partial safety factor from the approval  $\gamma_M = 1,5$  was considered. <sup>2)</sup> For the determination of the load action the partial safety factor from the approval  $\gamma_M = 1,5$  for material resistance and  $\gamma_F = 1,4$  for load actions were considered. <sup>3)</sup> The specified values apply regardless of center distances and edge distances.

# **Technical Characteristics**



### **Processing in new concrete**


Ankergröße			TSM BC 12
Effective anchorage depth	h <sub>ef, new</sub>	[mm]	40 - 120
Minimum edge distance	C <sub>min</sub> ≥	[mm]	0,5 x h <sub>ef, new</sub>
Minimum spacing	S <sub>min</sub> ≥	[mm]	80
Minimum base material thickness	h <sub>min</sub>	[mm]	h <sub>ef</sub> + concrete cover
Characteristic edge distance	C <sub>cr, N</sub>	[mm]	1,5 x h <sub>ef, new</sub>
Characteristic spacing	S <sub>cr, N</sub>	[mm]	3 x h <sub>ef, new</sub>
Design value of tension load in cracked concrete C 20/25 $^{1)3}$	N <sub>Rd, min</sub>	[kN]	7,1
	N <sub>Rd, max</sub>		17,6
Design value of tension load in non-cracked concrete C 20/25 $^{1133}$	N <sub>Rd, min</sub>	[kN]	10,1
	N <sub>Rd, max</sub>		24,8
Design value of shear load in cracked and non-cracked concrete C 20/25 bis C 50/60 $^{1\!\!13\!\!1}$	V <sub>Rd</sub>	[kN]	32,6
Permissible tension load in cracked concrete C 20/25 <sup>2) 3)</sup>	N <sub>zul, min</sub>	[kN]	5,1
	N <sub>Zul, max</sub>		12,6
Permissible tension load in non-cracked concrete C 20/25 <sup>2] 3)</sup>	N <sub>Zul, min</sub>	[kN]	7,2
	N <sub>Zul, max</sub>		17,7
Permissible shear load in cracked and non-cracked concrete C 20/25 bis C 50/60 $^{\mbox{$2/3$}}$	V <sub>per</sub>	[kN]	23,3

<sup>1)</sup> For the determination of the design value the partial safety factor from the approval  $\gamma_{M} = 1,5$  was considered. <sup>2)</sup> For the determination of the load action the partial safety factor from the approval  $\gamma_{M} = 1,5$  for material resistance and  $\gamma_{F} = 1,4$  for load actions were conside-

red. <sup>3]</sup> The specified values apply regardless of center distances and edge distances.

### **Installation Instructions**





- 1) Create borehole.
- 2) Clean the borehole thoroughly.
- 3) Discard three full strokes of composite mortar then inject composite mortar (optional).
- 4) Screw in concrete screw.
- 5) Hammer spacer onto screw head (optional).